



***Jogging Kit
For Track'r™ Pet Bicycle Trailer
Care & Use Guide***

Congratulations on your purchase of the Jogging Kit for Solvit Products Track'r™ Pet Bicycle Trailer. This kit allows you to quickly convert your pet trailer to a pet jogger. No tools are required.

Assembly:

Step 1: Make sure the tow bar is locked into place in the “storage” position under the trailer.

Step 2: Attach the jogger wheel: The jogger wheel attaches to the lower front center of the trailer. The male extension at the front rail of the trailer slips into the female portion of wheel bracket. Hand tighten the knob to secure the wheel to the trailer.

Step 3: Attach the push handle to the rear of the trailer: The push handle has 2 black plastic saddles and two cotter pins on either side. Snap the saddles to the rear trailer frame at the points where the fabric covering is cut away from the steel tube frame. Line up the holes on the saddles with the corresponding holes on the rear trailer frame. Insert the cotter pins, two on each side, to secure the push handle to the trailer.

WARNING: Always make sure the rear door is closed fully after your pet has been loaded and the jogger is in use.

Safety

- The trailer is equipped with reflectors at the front and rear of the cabin and on each wheel. There is also a reflective strip across the top rear of the cabin. When using your jogger at dusk or after, use a battery powered light on the jogger.
- The jogger is intended to carry pets only. No human passengers!
- Always jog with the rear door closed. When riding, your dog should always be secured with the safety leash adjusted to the correct length.
- Do not exceed the recommended weight capacity. Check tire inflation before every ride.